

THERMO MATERIALS®

THERMOLENE® SEBS PVC RESTORATION SPECIFICATION

Disclaimer: This document is intended as a Scope of Work and as such is written in a general manner. If actual project conditions are such as to be outside the scope of the normal waterproofing practices that are referenced in this document, steps should be taken to ensure the restoration remains in compliance with nationally recognized waterproofing practices such as those found in the National Roofing Contractors Association Manual.

The following covers the installation of a **SEBS Repair and Restoration System** for a properly prepared aged PVC roof.

REQUIRED MATERIALS

1. Surface Primer – [Thermopoxy™](#) (200-250 sq ft/gal)
2. Reinforcement Fabric – [Thermopolyester SB-075](#) (6" width minimum)
3. Flashing Mastic – [Thermolene® SEBS Mastic](#) (20 linear feet average per gallon of completed 3-course 6" wide)
4. Drains – [Thermolene® SEBS Reflective](#)
5. Base Coat – [Thermolene® SEBS Reflective](#) (white or gray)
6. Surface Coat – [Thermolene® SEBS Reflective](#) (white)

RECOMMENDED THERMO SYSTEM

1. All existing surface contaminates such as asphaltic mastics, peel and stick membranes or other roofing materials shall be removed to expose the underlying surface to which new materials are to be applied.
2. All surfaces to receive roofing or flashing materials shall be thoroughly cleaned using a high-pressure spray washer, with a minimum of 3,000 psi, and **clean water**, to remove all loose debris, dirt and other buildup. In areas where pressure washing would be prohibited due to existing substrate conditions, prepare these areas by hand using clean water only. Allow surface to completely dry.
3. Upon the completion of the initial surface preparations, apply a uniform ½-gal/sq of [Thermopoxy™](#) Surface Primer to the entire roof surface to be coated. Application techniques shall be such to allow for proper application rates to all high and low spots, as well as angles in the roof surface. Allow application to fully cure.
4. After full cure of [Thermopoxy™](#) Surface Primer, all seams shall be 3-coursed, defined as a layer of [Thermopolyester SB-075](#) Reinforcement Fabric sandwiched between 2 layers of [Thermolene® SEBS Mastic](#) Flashing Mastic at a rate of 20 linear ft/gal having a minimum width greater than that of the [Thermopolyester SB-075](#) Reinforcement Fabric. Apply the [Thermopolyester SB-075](#) Reinforcement Fabric without tenting, fishmouths or wrinkles.
5. All roof penetrations, curbs, transitions points, vents, drains and scuppers shall also be 3-coursed as defined in step #3. Apply the [Thermopolyester SB-075](#) Reinforcement Fabric without fishmouths or wrinkles.
6. Roof to wall transitions and metal counterflashings, shall be 3-coursed as defined in step #3. Apply the [Thermopolyester SB-075](#) Reinforcement Fabric without fishmouths or wrinkles.
7. All drains and scuppers perimeter, a minimum of 40", shall be additionally 3-coursed, defined as a layer of [Thermopolyester SB-075](#) Reinforcement Fabric fully embedded in 2 layers of [Thermolene® SEBS Reflective](#) Base Coat at a rate of 1½-gal/sq having a minimum width greater than that of the [Thermopolyester SB-075](#) Reinforcement Fabric. Apply the [Thermopolyester SB-075](#) Reinforcement Fabric without fishmouths or wrinkles.
8. After full cure of preparations, to all areas of the roof to be coated, including any vertical transitions; apply a uniform 1½-gal/sq of [Thermolene® SEBS Reflective](#) Base Coat. Application techniques shall be such to allow for proper application rates to all high and low spots, as well as angles in the roof surface. Allow application to fully cure.
9. After full cure of [Thermolene® SEBS Reflective](#) Base Coat, apply a uniform 1½-gal/sq of [Thermolene® SEBS Reflective](#) Surface Coat using a crosshatch pattern to that of the [Thermolene® SEBS Reflective](#) Base Coat. Application techniques shall be such to allow for proper application rates to all high and low spots, as well as angles in the roof surface. Allow application to fully cure.
10. Follow NRCA guidelines for any ponding areas on the roof.
11. Inspect all finished surfaces for proper mils and deficiencies in the application. Where necessary apply additional [Thermolene® SEBS Reflective](#) Surface Coat at a rate of 1-gal/sq to any deficient areas.

Warranty: If applied according to our published specifications and guidelines and after successfully passing a final inspection and then accepted by Thermo Manufacturing Systems, LLC, this system would qualify for our 10-Year Labor & Material Warranty. Call for details regarding warranty application documentation requirements and warranty fee schedule. Optional Thermo Materials® Mastics and Sealants are available. Call for details.



Eco-friendly, Sustainable Building Restoration Specialists